

(800)736-2114



PARTS LIST:

- 1- Exhaust Canister
- 1- Servo Eliminator (21-1002)
- 1- 6x16 Allen Bolt
- 1- 6mm Washer
- 1- 6mm Nyloc Nut

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>



# 1100 Slip-on Exhaust

2021

- 1) Remove seat.
- 2) Remove exhaust valve cable from pipe \*FIG (A) and from servo motor \*FIG (B). Set cable aside.
- 3) Remove servo motor (2- allen bolts) \*FIG (B). Snip zip-tie and unplug. \*FIG (C)
- 4) Install electronic Servo Eliminator by plugging it in.
- 5) Remove stock exhaust canisters (2- bolts, 1- clamp).
- 6) Remove stock exhaust mounting brackets.
- 7) Remove catalytic converter (1- clamp).
- 8) Transfer exhaust gasket from catalytic converter to WerkesUSA canister inlet.
- 9) Install WerkesUSA Canister (use stock clamp, and supplied 6mm bolt washer, and nut). \*FIG (D)
- 10) Replace seat.
- 11) Clean exhaust with WD-40 (or similar) before starting.



**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WDSCR4