



<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>

# 2017 KTM 390

(800)736-2114

## Duke/RC

- REMOVE:
- 1) Remove side exhaust canister (1- bolt, 1- clamp)
  - 2) Remove lower engine shroud \*RC model only\* (2 bolts near front tire, 2- bolts underneath engine, pull out side panels).
  - 3) Remove lower engine shroud rear mounting bracket \*RC model only\* (3- bolts).
  - 4) Remove center exhaust chamber (3- bolts, 1- clamp). Remove u-nuts from frame to avoid loss. For part identification refer to \*FIG (A)
- INSTALL:
- 1) Transfer one of the red grommets (and spacers) from the stock exhaust chamber to the corresponding point on the supplied Chamber Delete.
  - 2) Transfer both stock exhaust gaskets to the supplied Chamber Delete.
  - 3) Maneuver Chamber Delete into position. Use stock clamp (without stop) at upper exhaust joint \*leave loose. Use stock bolt and supplied 6mm Nut at frame mount. \*leave loose. \*FIG (B)
  - 4) Install side exhaust canister using stock hardware, gasket, and clamp (without stop).
  - 5) Adjust to desired fitment and tighten all hardware.
  - 6) Clean exhaust with WD-40 (or similar) before starting.

**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***



### PARTS LIST:

1- Chamber Delete 1- 6mm Ny-loc Nut

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WKT391D2