



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

**(800)736-2114**

# 2021 KTM 390 DUKE

- REMOVE: 1) Remove stock exhaust canister (1- bolt, 1- clamp, 1- gasket).
- INSTALL: 1) Install WerkesUSA GP Canister at stock location with bracket to backside of mount (use stock gasket, bolt and clamp).  
2) Clean exhaust with WD-40 (or similar) before starting.

PARTS LIST:  
1- WerkesUSA GP Canister

**"IMPORTANT"** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **"IMPORTANT"**



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

**WKT393**