

Part Number: KTM-390D-17

Description: Dual Saddle

Fitment: 2017 - 2022 KTM 390 Duke

Revision: 1



Tools Required	Parts List
	PRE-INSTALLED ON SEAT 1 #SP00958 Chrome Latch Pin 2 #SP00296 8mm Washers 1 #SP00137 8mm Hex Nut

Saddle mounts like stock and integrates with the OEM key lock. Brackets come preinstalled on the saddle.

1. Remove stock seat.
2. To install the Corbin saddle, simply slide the saddle into place nose first to engage the tongues and lower the rear into place. Push firmly on the passenger platform to latch until you hear two clicks. (Figure 1)

NOTE: Saddle latch pin is adjustable to provide a perfect fit. Simply release the jam-nut and unscrew the latch pin to add or remove spacers as needed. When re-installing, be sure the cut portion faces to the right of the motorcycle. (Figure 2).

Enjoy your new saddle!



FIG 1



FIG 2

Questions? Give us a holler...
800-223-4332
tech@corbin.com