

**Part Number:** RE-C35-S & RE-C35-P

**Description:** Solo & Pillion Saddles

**Fitment:** 2022-2023 Royal Enfield Classic 350

**Revision:** 1



Tools Required	Parts List
2 (1/2") Socket Wrenches 1 (10mm) Socket Wrench	<b>SOLO SEAT</b> 1 #SP00155 5/16" x 18 x 4.5" Hex Head Bolt 2 #SP00215 5/16" Flat Washers 1 #SP00689 5/16" Nylock Nut <b>PILLION SEAT</b> 1 #P11358 Corbin Bracket 4 #SP00104 m6 x 16m Hex Head Bolts 4 #SP00102 3/16" Flat Washers

1. Begin by removing your stock seat. To do this, you need to remove the hex head bolt under the seat, using a 6" extension and socket wrench.

2. Install the Corbin Solo saddle by slipping the front tongue into the base of the gas tank, lower the seat so the U-shaped brackets drop straight down (Figure 1) and secure with the provided 5/16" hex head bolts, flat washers and Nylock Nut (Figures 2 & 3).

**NOTE:** Brackets on the Corbin Solo saddle are adjustable to assure a perfect fit.

3. If you are using the Pillion, install the Pillion onto the Solo saddle, using the supplied Corbin bracket, m6 hex head bolts and 3/16" flat washers (Figure 4). Then install the seats on the bike as outlined in Step 2.



Questions? Give us a holler...  
**800-223-4332**  
tech@corbin.com