

**Part Number:** S-VSTRM-F & S-VSTRM-R

**Description:** Front & Rear Saddle

**Fitment:** 2006 Suzuki V-Strom

**Revision:** 2



Tools Required	Parts List
5/32" Allen wrench Phillips screwdriver Loctite® or similar	1 #A00854 Mounting bracket 2 16mm flat head allen bolts

**NOTE:** We recommend the use of Loctite® or other threadlock compound when assembling parts on your motorcycle.

1. Remove your stock seat.
2. Remove the stock key lock system from the bike using a phillips screwdriver. (Figure 1)
3. Install the Corbin bracket where you just removed the stock locking mechanism, using the supplied 16mm flat head Allen bolts. Tighten to 10 ft. lbs. and use Loctite®. (Figure 2).
4. Reinstall the stock key lock system to the Corbin bracket using the stock bolts. (Figure 3)
5. Front saddle secures to the bike with a tongue in the front and latch mechanism in the rear. Simply slide the saddle into place nose-first then lower onto the latch pin. Push down until you get TWO clicks. To remove, just squeeze the tab to release the lock.
6. Rear saddle installs with two tongues in the front and your stock latch in the rear. Simply slip the front tongues under the brackets, align with rear lock and push down. To remove the rear saddle, turn the ignition key at the rear of the saddle and lift up.



**Questions? Give us a holler...**  
**800-223-4332**  
**tech@corbin.com**