

Part Number: T-R-3-FLIP

Description: Rumble Seat

Fitment: Triumph Rocket III

Revision: 3



| Tools Required | Parts List |
|---|--|
| 10mm socket or combination wrench 13mm socket or combination wrench Loctite® or similar | Seat / fender bracket 2 Preinstalled brackets on seat 2 Hex head cap screws 6m x 35 x 1.0 2 6m flat washers 2 5/16" Chrome washers 2 Chrome button head bolts 5/16" x 18 x 3/4" |

1. To install your new Corbin saddle, you're first going to have to remove the stock seat (of course). If you've lost your owner's manual, all you need to do is use your key to unlatch the front seat, then remove three bolts from the bracket that holds the rear seat down to your fender. These are located under the front seat.

2. Begin your installation by attaching the included seat bracket to the front of the fender with the two included 6m hex head bolts and matching flat washers. We recommend using loctite®. Align the bracket as shown in Figures 1 with side arms parallel to the ground and tighten to 8 ft. lb.

3. Slide the seat onto the bike nose first engaging the nose tongue into the bracket on your frame.

4. With the saddle lowered down onto the fender, the two brackets mounted on the side of the seat should line up with the threaded holes in the bracket mounted to your fender. Once the holes are aligned, secure the saddle in place with the included Chrome button head bolts and flat washers (Figure 2). Assure seat brackets do not contact fender or it may scratch. Tighten to 6 ft. lbs.

NOTE: Because the seat is brand new, the rubber bumpers may be a little stiff. Due to this, you may need to bump the seat forward with the ball of your hand to get the holes to align properly.



FIG 1



FIG 2

Questions? Give us a holler...
800-223-4332
tech@corbin.com