

**Part Number:** Y-LNR-H

**Description:** Hollywood Solo Saddle

**Fitment:** 2006 Yamaha Roadliner & Stratoliner

**Revision:** 1



Tools Required	Parts List
10 mm Open Wrench	Hollywood Solo Saddle

**Installation:** Corbin's Hollywood Solo Saddle installs on your bike like stock using a tongue in the rear and your stock key lock system. Latch brackets come preinstalled on the saddle for immediate installation.

1. To install your Hollywood Solo saddle, simply slide the rear of the saddle into your stock fender bracket (Figure 1). Then lower the front of the saddle to the motorcycle latch (Figure 2) and push down on the saddle until you hear the lock click.

**NOTE:** The front and rear brackets can be adjusted.

**NOTE:** To ease installation until the rubber bumper on the basepan break in, it may be necessary to add a washer between the seat pan and latch bracket. This will make it easier to latch.



Questions? Give us a holler...

**800-223-4332**

[tech@corbin.com](mailto:tech@corbin.com)