

www.evotech-performance.com BMW S 1000 R Radiator Guard Installation Instructions


## **Installation Instructions**




Kit Contents PRN014330-014331


- (A) 2 x M5 x 8 Black Button Head
- B 4 x Neoprene
- © 10 x Rubber Bung










































































## 27








Locate round holes amongst hexagons.

Push Rubber Spacer through from the back of the guard so Hexagonal shape sits on the front face


## 28







































## 🔨 ESSENTIAL CHECKS 🔨



It is recommended that periodic inspections are made to ensure that dirt and debris have not become trapped between the guard and the radiator/oil cooler. Such dirt and debris would reduce the cooling efficiency of the radiator/oil cooler.

It is recommended that periodic inspections are made to ensure that all fixings are fully tightend.





www.evotech-performance.com