

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

DUCATI MONSTER 937

FRONT TURN SIGNALS

1 Remove 2 bolts underneath stock signal housing (Photo 1)



2 Slide housing off and unplug connector (Photo 2)



3 Remove bolt and slide off stock turn signal (Photo 3)



4 Take plastic covers apart (Photo 4)



NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

FRONT TURN SIGNALS

- 5 Take new blinkers and snap the lip into the groove of the plastic cover (Photo 5 and 6)
- 6 Take other half of plastic cover and snap it back together (Photo 7)
- 7 Reinstall stock bolt
- 8 Plug connector in and mount housing bracket onto bike (Photo 8)

