

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

YAMAHA R3

FRONT TURN SIGNALS

- 1 Remove inner fairing shield screws on both sides of the bike. (Picture 1)
- 2 Remove left and right upper fairing covers. (Picture 2 and 3)
- 3 Unplug OEM connectors and remove retaining clip to slide off stock turn signals. (Picture 4 and 5)
- 4 Take new signals, and remove long screw from the back of the lens to separate the little plastic block. (Picture 6)
- 5 Slide blinker into fairing cavity and use the little block and screw to mount to the bike. (Picture 7 and 8)

