

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

INDIAN BOBBER SCOUT

FRONT TURN SIGNALS

- 1 Remove stock turn signal retaining bolt using a 10mm wrench and 5mm allen key (Photo 1 and 2)
- 2 Unplug connectors behind headlight
- 3 Remove allen bolt for stock signal using a 4mm allen key. You will be reusing this bolt to mount new turn signals (Photo 3 and 4)
- 4 Take new signals and remove the top sheet metal cover from both sides (Photo 4)



NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

FRONT TURN SIGNALS

- 5 Take flat cover plate and top sheet metal cover and mount onto rubber signal mount using the stock bolt and supplied M6 nut (Photo 5, 6, 7)

- 6 Install new turn signal by screwing to top sheet metal

- 7 Take rubber mount, wrap back around fork, reinstall retaining bolt, route connectors back to OEM connector and plug back in

