



## MOUNTING SUGGESTIONS:

### Harley-Davidson® FXLR Low Rider / FLSB Sport Glide 2018 Solo and Passenger Seat

<b>Hardware (Included):</b>	<b>Solo:</b> <i>(none)</i>	<b>Passenger seat:</b> 1/4"-20 x 1" buttonhead Allen bolt Slotted spool washer Fender nut
-----------------------------	-------------------------------	----------------------------------------------------------------------------------------------------

<b>Tools needed:</b>	Flat screwdriver 5/32" Allen wrench 3/8" hex wrench
----------------------	-----------------------------------------------------------

#### Removal of Stock Seat:

1. Remove the rear 1/4"-20 fender screw with a screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
2. Slide the seat up and back to disengage the front bracket and remove the seat.



3. Remove the handstrap with a 3/8" hex wrench.

## Installation of Mustang seat:

*Solo:*

1. ***If installing just a solo***, remove the plug from the front fender mount. Remove the plastic C-clip from the fender nut at the rear of the fender and remove the nut from under the fender for use in step 3. **Do not lose this clip.**
2. ***If installing a solo and a passenger seat***, leave this fender nut in the rear position, and use the fender nut provided with the passenger seat in step 3.
3. Install the fender nut in the empty fender hole using the C-clip. Insert the plug into the rear hole if you are not installing a passenger seat.



4. Engage the Mustang solo's front mounting bracket into the frame mount behind the tank.
5. Align the rear bracket with the fender nut. If installing the solo alone, secure the bracket to the fender with the stock screw. If installing a passenger seat, secure to the fender with the supplied  $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer.

*Passenger seat:*

1. Remove the stock screw mounting the back of the solo and replace with the supplied  $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer. The slotted washer should sit directly on top of the solo bracket.

2. Align the slot at the front of the Mustang passenger seat with the slotted spool washer mounted above the solo seat's rear bracket, and slide the seat forward to engage the washer.



3. Align the rear bracket with the rear fender nut and secure with the stock screw.

**Note:** on Sport Glide models, there should be appx. 1/2" clearance between the Mustang seat and the saddlebag levers.

**Enjoy the comfort and custom look of your new Mustang seat!**





These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at [www.mustangseats.com](http://www.mustangseats.com).

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75721, 75722, 75724, 75725, 79041, 79042, 79043

**You are cordially invited to**  
**— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.