



MOUNTING SUGGESTIONS:

Yamaha V-Star 1100 Classic/Silverado '00-09 – Solo and Passenger Seat

Hardware:	Stock 8mm screws/nut White nylon washer
Tools needed:	Metric wrenches

Removal of stock seat:

1. Remove the 8mm screw or nut from the fender.

2. Slide passenger seat back to remove.



3. Remove 8mm screw behind the solo.

4. Slide solo back and up to remove.

Installation of Mustang seat:

1. Slide nose bracket on the front of the solo into the receiver at the base of the gas tank.

2. Secure the rear of the solo to the fender with the stock 8mm screw.

3. Slide the passenger seat's front bracket under the fender receiver and align the rear bracket with the fender mount.

4. On models with a fender stud, put the white nylon washer between the fender and the seat's rear bracket and secure with the stock nut. On models with a fender hole, secure the bracket to the fender with the stock 8mm screw.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75910, 75912, 75913, 75914, 75916, 75917, 79240, 79242, 79243, 79244, 79246, 79247

**You are cordially invited to
— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.