



## MOUNTING SUGGESTIONS:

### Harley-Davidson® Sportster 1982-2003 Solo and Passenger Seats

<b>Hardware (Included):</b>	<b>Solo:</b> Black nylon washer (3.3 gallon only)	<b>Passenger seat:</b> 1/4"-28 x 1" buttonhead Allen bolt (1982-1995) 1/4"-20 x 1" buttonhead Allen bolt (1996-2003) Nylon washer Slotted spool washer
<b>Tools needed:</b>	Phillips screwdriver 5/32" Allen wrench	

**Note: Certain Mustang seats will not install with specific fuel tanks. Please be sure your seat is correct for your tank size.**

#### Removal of stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.



2. If one-piece, slide the seat up and back to disengage the front bracket and remove the seat.

3. If two-piece, locate and remove fender bolt between the solo and passenger seat, then remove passenger seat, and then solo seat.

## Installation of Mustang seat:

### *Solo:*

1. Insert nose tab into frame mount under tank. A firm downward chop to the nose will push it closer to the tank.
2. Align rear bracket with fender nut and position the nylon washer (if needed) between the bracket and the fender mount. If installing solo alone, secure the bracket to the fender with the stock screw. If installing a passenger seat, secure to the fender with the supplied  $\frac{1}{4}$ "-28 x 1" (1982-1995) or  $\frac{1}{4}$ "-20 x 1" (1996-2003) buttonhead bolt and slotted spool washer.



*Passenger seat:*

**Note: Mustang passenger seat will not fit with stock solo.**

1. Remove the stock screw mounting the back of the solo and replace with the supplied  $\frac{1}{4}$ "-28 x 1" (1982-1995) or  $\frac{1}{4}$ "-20 x 1" (1996-2003) buttonhead bolt and slotted spool washer. The slotted washer should sit directly on top of the solo bracket.
2. Align slot at front of passenger seat with the slotted spool washer mounted above the solo seat's rear bracket, and slide the seat forward to engage the washer.
3. Align rear bracket with rear mount in fender, position the washer between the bracket and the fender mount, and secure with stock screw.

**Enjoy the comfort and custom look of your new Mustang seat!**



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at [www.mustangseats.com](http://www.mustangseats.com).

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75117, 75118, 75491, 75700, 75702, 75703, 75707, 75708, 75758, 75759, 79106, 79126, 79136, 79446

You are cordially invited to  
**— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.