

EVOTECH®
P E R F O R M A N C E

www.evotech-performance.com

BMW SP Connect Sat Nav Mount

Installation Instructions





For SP Connect mirco stem mount alu Part number #53122
follow instructions 1 - 16


For SP Connect anti vibration module Part number #53135
follow instructions 17 - 29





Kit Contents PRN014377-015031


- | | |
|-----------------------------------|---|
| (A) 1 x M6 x 16 Countersunk Screw | (L) 2 x M5 Black Washer |
| (B) 1 x Pivot Plate | (M) 2 x M4 x 5mm Button Head Bolts |
| (C) 1 x SP Connect Plate | |
| (D) 1 x Spanner | |
| (E) 2 x M5 x 10mm Caphead Bolts | Sub Kit |
| (F) 2 x P-clips (No.1) | (N) 1 x Right Hand Arm |
| (G) 2 x P-clips (No.2) | (O) 1 x Left Hand Arm |
| (H) 2 x P-clips (No.3) | (P) 1 x Spacer |
| (I) 2 x P-clips (No.4) | (Q) 2 x M8 x 45mm Flange Bolt |
| (J) 2 x Lobe Screw | (R) 2 x M5 x 12mm Black Button Head Bolts |
| (K) 2 x Locking Washer | (S) 1 x M5 Nylock Nut |



















































Kit Contents PRN014377-015031


- | | |
|-----------------------------------|---|
| (A) 1 x M6 x 16 Countersunk Screw | (L) 2 x M5 Black Washer |
| (B) 1 x Pivot Plate | (M) 2 x M4 x 5mm Button Head Bolts |
| (C) 1 x SP Connect Plate | |
| (D) 1 x Spanner | |
| (E) 2 x M5 x 10mm Caphead Bolts | Sub Kit |
| (F) 2 x P-clips (No.1) | (N) 1 x Right Hand Arm |
| (G) 2 x P-clips (No.2) | (O) 1 x Left Hand Arm |
| (H) 2 x P-clips (No.3) | (P) 1 x Spacer |
| (I) 2 x P-clips (No.4) | (Q) 2 x M8 x 45mm Flange Bolt |
| (J) 2 x Lobe Screw | (R) 2 x M5 x 12mm Black Button Head Bolts |
| (K) 2 x Locking Washer | (S) 1 x M5 Nylock Nut |



















B


SP Connect
Part #53135



Supplied with
#53135









Repeat
Both Sides










ESSENTIAL CHECKS

It is recommended that periodic inspections are made to ensure that all bolts are tightened to the specified torque settings.

Should the bike be involved in an accident a thorough inspection should be made and any components that have taken an impact, no matter how small, be replaced



EVOTECH®
P E R F O R M A N C E

www.evotech-performance.com