



401 South Grand Ave., Santa Ana, CA 92705  
 Tel: 714.550.6070 Fax: 714.550.9661 www.twobros.com

**2016-17 Can Am SPYDER F3T  
 S1R Canister Slip On System  
 Part# 005-46604-S1R**




Qty.	Description	Part Number
1 x	15" S1R Muffler	Varies
1 x	Slip Tube	005-39304S
1 x	Bracket	005-466-B
1 x	8x16mm Bolt	005-SH816
1 x	8mm Flange Nut	005-FN8
2 x	45mm Springs	005-S45
1 x	S1R Muffler Clamp Vertical	005-2C-S1
1x	Spring Puller	005-SP



**Installation Instructions**

1. Make sure the vehicle is completely cool before starting the installation.
2. Loosen OEM slip on clamp bolt.
3. Loosen OEM muffler bolt and remove slip on muffler from the vehicle.
4. Loosely install TBR slip tube and S1R muffler and slide the muffler clamp on the canister. (picture 1)
5. Using the OEM muffler bolt & nut along with the supplied hardware install the TBR bracket as shown. (picture 2)
6. Ensuring that the exhaust is installed properly, begin to tighten the bracket bolts and OEM slip tube clamp. (picture 3)
7. Install the supplied S1R retention springs.
8. Before you run the bike, clean off all fingerprints and dirt, as any oily residue will etch the metal and become somewhat permanent when the system gets hot. Run the bike and enjoy. It is normal for some white smoke to appear the first time you start the bike. This is packing/manufacturing oil from inside the pipe burning off. Check for gaps or leaks. If you find a leak, a little high temperature silicon sealant should fix it. After 50 to 100 miles, recheck all fasteners for tightness.



**Care & Cleaning**

**Care & Cleaning**

Keep system free of dirt and moisture. Store in a cool, dry place. Make sure vehicle is completely cool before maintenance.

**Stainless Header System:** Polished stainless steel pipes will turn a light golden hue after a few heat cycles, this is a normal characteristic of high quality stainless steel. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Titanium Header System:** Polished titanium pipes will experience color shift ranging from deep blue/purple through amber after a few heat cycles. This is a normal characteristic of high quality titanium. Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Polished Aluminum Canisters:** Use an aluminum or mag wheel polish to restore the bright finish to factory spec.

**Brushed Aluminum Canisters:** Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth.

**Carbon Fiber Canisters:** Clean using a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

**Titanium Mufflers:** For cleaning use a mild water based spray cleaner. Always apply cleaner or polish with a soft, clean cloth. Always make sure the fiberglass packing inside is in good condition and not burned out, as exhaust heat inside an empty canister will deteriorate the carbon fiber sleeve. TBR sells repack kits (Road - #005-10038, Offroad - #005-10038MX) that include everything you need to easily do it yourself.

Repack all road canisters every 3,000 miles. Part #005-10038

Repack all offroad canisters after every 10 hours of use. Part #005-10038MX

**NEVER** dyno test your bike with carbon fiber or titanium canisters installed - the intense heat and lack of cooling air can quickly burn through the canister material. Two Brothers Racing does not provide a warranty for burned canisters.

**Warranty**

Two Brothers Racing products are intended for closed course competition purposes only, and therefore are sold "as is" without warranty. Two Brothers Racing specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products or parts.

**IMPORTANT - PLEASE READ CAREFULLY**

*Two Brothers Racing products are intended for closed course competition purposes only. We recommend that this performance part be installed by a qualified motorcycle technician. If you have any doubts as to your ability to install this performance part, please consult with your local motorcycle dealer. Read all instructions first before starting installation. Make sure the motorcycle and exhaust system are completely cool before starting the installation. Be sure to save all stock components for possible use later.*

*\*\*This product has not been tested with all available accessories and some items may cause excessive heat. Excessive heat may cause damage to your vehicle. Two Brothers Racing will not be responsible for damaged parts.*