

## Denali Solo Guage Mount Speedometer

Triumph Bonneville, Thruxton & Scrambler

MBK.11.10100 Instructions Rev:00

### PLEASE READ BEFORE INSTALLING

TWISTED THROTTLE products should be installed by a qualified, experienced motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. TWISTED THROTTLE takes no responsibility for damages caused by improper installation.


All screws, bolts, and nuts, including all replacement hardware provided by TWISTED THROTTLE should be tightened to the torque specified in the OEM maintenance manual for your motorcycle. If no torque specifications are provided in the OEM maintenance manual, the following torques may be used:

M5.....	3.5 ft-lbs (5 Nm)
M6.....	7 ft-lbs (9.6 Nm)
M8.....	13 ft-lbs (18 Nm)

All screws, bolts, and nuts should be checked after driving the first 30 miles (50 km) to ensure that all are tightened to the proper torque.


Medium strength liquid thread-locker (i.e., "Locktite") should be used to secure all screws, bolts, and nuts.

Distributed by:	
Twisted Throttle LLC 570 Nooseneck Hill Rd Exeter, RI 02822	phone: 855.255.5550 fax: 401.223.6955 www.twistedthrottle.com



### Installation Instructions

**1**  
Mounting Bracket




MBK.11.002  
Qty.....1

**2**  
Lens Head Screw




M8x20.....ISO 7380  
Qty.....2

**3**  
Washer



M8.....DIN 125  
Qty.....2

**4**  
Spacer



OD: 12.7mm, ID: 8.1mm, L: 6.3mm  
Qty.....4

**5**  
Lens Head Screw



M8x25.....ISO 7380  
Qty.....2

**Step One:** Remove the OEM Guage cluster from the top side of the upper triple tree. Next install the speedometer to the new mounting bracket (#1), there is enough room in the housing to also hide the connector from the tachometer. Use the supplied hardware to mount the speedometer to the underside of the upper triple tree. Note if you have stock handlebars you will need to use four spacers and the longer bolts to gain clearance. If the bike is equipped with clip-on's, only two spacers and the shorter bolts will be required.

